

Wall Mounting Above View Ceiling Tile

Screw the tile to the wall (preferable but not necessarily to studs).

Use 2 wood screws / tile

- longer screws around 1.5"
- Phillips, small flat heads
- larger threads (#6 - #10)

Pre – drill 2 holes, either on top or bottom or on opposite sides for counter sinking.

Start screwing with power drill. **IMPORTANT**, when screw is near surface switch from power drill to hand drill to countersink screws, just below surface.

Spackle to conceal screws for finished surface.

Spackle seams between tiles if desired. Touch up paint if needed.

September 2, 2020